

# Quick Start Guide

NEP-8323, NEP-8186

Multi Output Linear Mode Remote Programming Laboratory Grade Power Supply



QR code for user manual download



## 1 Accessories



AC power cord




USB cable



Output cable with right angle safety plug and crocodile clip


## 2 AC Voltage Selection

- Please select correct Input AC voltage before connect AC power cord.
- The AC selection switch is location on the bottom of power supply.
- Select 115 for 100Vac to 126Vac
- Select 230 for 207Vac to 253Vac




## 3 Indications, buttons and knobs

### Front Panel



- 1 - Main Power Switch
- 2 - Output ON/OFF button
- 3 - Preset 1/2/3 selection and LED indication
- 4 - Main output Current limit adjust knob and Menu entry
- 5 - Main output Voltage limit adjust knob
- 6 - C.V./C.C. mode indication
- 7 - Ammeter
- 8 - Voltmeter
- 9 - Auxiliary Output 5V indicator
- 10 - Wave Form generation cycle running indicator
- 11 - Remote control indicator
- 12 - Adjustable Main Output
- 13 - Auxiliary output 1 for 3.3V/5V
- 14 - Auxiliary output 2 for 12V

### Back Panel



- 1 - Auxiliary 1 3.3V/5V selection
- 2 - USB Remote Control port
- 3 - Cooling Fan
- 4 - Ethernet port (Ethernet model only)
- 5 - AC power plug
- 6 - AC FUSE

# 4

## Basic Menu



### Enter MENU

Long press on **CURRENT** Knob to get into the menu mode, second long press to exit & confirm new settings



### Select feature and adjustment

press the **VOLTAGE** Knob to either get into the selected feature for adjustment or to get back to scroll mode for another feature selection.

### MENU SEQUENCES

UVL Set ► UCL Set ► dV/dt Run ► dV/dt Set ► FACS Set ► Pu Set ► Uns Set ► Disp Set ► tout Set

UVL Set - Upper Voltage Limit

UCL Set - Upper Current Limit

dV/dt Run - Operation of waveform generation

dV/dt Set - Programming of waveform generation

FACS Set - Factory Reset

Pu Set - Power Up output off or output as the last shut down

Uns Set - USB or optional Ethernet selection


Disp Set - Brightness adjustment of LED display

tout Set - Timeout period of voltage & current display


# 5

## Output connection examples (using NEP-8323 as an example)

### Separate connection of 3 outputs



### Connect 2 outputs in series



### Connect 3 outputs in series

