

DEUTSCH**Festsender speichern**

1. Wählen Sie den gewünschten Sender aus.
2. Drücken Sie die **"MEM"** Taste. Im Display ist nun oben rechts die Anzeige „MEM“ zu sehen.
3. Wählen Sie mit den Tasten **"◀◀"** oder **"▶▶"** den gewünschten Speicherplatz aus. Sie können maximal 20 Radiosender abspeichern!
4. Drücken Sie die Taste **"ENTER"** um die Auswahl zu bestätigen. Es wird „SAVED“ im Display angezeigt. Danach wird der aktuelle Sendername wieder angezeigt.

Abrufen der gespeicherten Festsender

1. Drücken und halten Sie die Taste **"MEM"** bis eine Stationsnummer im Display zu sehen ist. Sie können dann die Taste loslassen.
2. Wählen Sie mit den Tasten **"◀◀"** oder **"▶▶"** den gewünschten Speicherplatz aus.
3. Um die Auswahl zu bestätigen drücken Sie die **"Enter"** Taste. Der Radiosender wird abgespielt.

ENGLISH**Store a preset station**

1. Select the desired radio station
2. Press the **"MEM"** button. The display now shows "MEM" at the top right.
3. Choose with the **"◀◀"** or **"▶▶"** button the station number where the radio station should be saved. You can store max. 20 radio stations!
4. Press the **"ENTER"** button to confirm the selection. "SAVED" is shown in the display. The current station name is then displayed again.

Recall a preset station

1. Press and hold the **"MEM"** button until a station number appear on the display. Then you can release the button.
 2. Choose with the **"◀◀"** or **"▶▶"** button the desired station number.
 3. Press the **"Enter"** button to confirm the selection. The radio station will be played.
-