

**S** Sandberg®  
**ACTIVE** 

# Hand Warmer Powerbank 10000


Quick guide

420-65




[www.sandberg.world](http://www.sandberg.world)


### Charge Powerbank







### Charge devices



**Hand Warmer**





Press  
2 seconds



Press  
2 seconds

**Flashlight**



Double click to turn on/off the flashlight



Support

<http://helpdesk.sandberg.world>

## Warranty

There is a five-year warranty on your Sandberg product. Please read the warranty terms and register your new Sandberg product at [www.sandberg.world/warranty](http://www.sandberg.world/warranty)

**5**  
Years  
Warranty

For information on handling electronic waste, see [www.sandberg.world/weee](http://www.sandberg.world/weee)

