


inolight CL 4 USB Anzünder



1. Allgemeine Hinweise

Vielen Dank, dass Sie sich für dieses hochwertige Produkt entschieden haben. Bitte lesen Sie diese Bedienungsanleitung vor dem ersten Verwenden aufmerksam durch und bewahren Sie diese für zukünftige Gelegenheiten zum Nachschlagen auf.

Sollten Sie technische Fragen haben, können Sie uns gerne jederzeit eine Email an service@telestar.de schreiben. Wir stehen Ihnen mit Rat und Tat zur Seite.

2. Sicherheitshinweise

Lesen Sie die Sicherheitshinweise sorgfältig durch, bevor Sie das Gerät in Betrieb nehmen. Beachten Sie alle Warnungen und Hinweise auf dem Gerät und in der Bedienungsanleitung.

- Vermeiden Sie Gewalteinwirkung auf das Produkt (z.B. mit einem scharfen Gegenstand).
- Bewahren Sie den Anzünder außer Reichweite von Kindern auf.
- Öffnen Sie das Produkt niemals. Dieses darf nur von autorisiertem Servicepersonal geöffnet werden.
- Der Anzünder darf nicht in Kontakt mit Wasser oder anderen Flüssigkeiten kommen.
- Um Wachsreste von den Polen (Abb. 4) zu entfernen, verwenden Sie z.B. eine Nagelfeile.
- Bitte verwenden Sie zum Aufladen des Anzünders ausschließlich die USB Buchse eines Laptops oder ein Mobilfunk-Ladegerät mit einer maximalen Leistung von 5V DC und 3000 mA. Bei unsachgemäßer Nutzung besteht Explosionsgefahr!
- Verwenden Sie den Anzünder nicht als Beleuchtung.
- Bitte halten Sie das Produkt von anderen und ihrem eigenen Gesicht, Haut und ungeeigneten brennbaren Substanzen fern und stellen Sie sicher, dass der Lichtbogen nach Gebrauch vollständig ausgeschaltet ist, um Gefahren zu vermeiden.

- Halten Sie das Produkt von offenen Flammen, direkter Sonneneinstrahlung und Temperaturen $>50^{\circ}\text{C}$ fern, um Überhitzung, Feuer oder Fehlfunktionen zu verhindern bzw. die Lebensdauer des Produktes zu verkürzen.
- Trennen Sie das Ladegerät unmittelbar nach dem vollständigen Laden vom Gerät.

3. Benutzung

Das inoLight CL 4 ist mit einem wiederaufladbaren Li-Ion Akku (3.7V, 280mAh) ausgestattet. Die Boostertechnologie des CL 4 erhöht die geringe Spannung des Akkus auf Halbsinus-Hochspannung (7kV bei einer Frequenz von 15 kHz) und erzeugt zwischen den Polen (Abb. 4) einen Lichtbogen mit extrem hoher Temperatur. Der Anzünder eignet sich somit bestens, um Zigaretten, Kerzen, Kamine und andere entflammbare Materialien zu entzünden und ist dank der Wiederaufladbarkeit eine umweltfreundliche Alternative zu mit fossilen Brennstoffen betriebenen Gas- oder Benzinfeuerzeugen.

- Laden Sie den Anzünder vor der ersten Verwendung vollständig mithilfe eines USB Anschlusses eines Laptops oder eines Handyladegerätes (max. DC 5V, 3000 mA) auf. Verbinden Sie hierzu die Micro-USB Buchse des Anzünders (Abb. 1) mit einem USB Anschluss und einem Ladegerät über das im Lieferumfang enthaltene Kabel.
- Der Ladevorgang dauert ca. 2-3 Stunden. Trennen Sie nach Abschluss des Ladevorgangs den Anzünder vom Ladegerät. Es ist nun betriebsbereit.
- Schieben Sie die Sicherheitsklappe (Abb. 2) mit dem Finger nach oben und betätigen Sie den Zündknopf (Abb. 3). Führen Sie nun das anzuzündende Objekt an den Lichtbogen (Abb. 4).
- Der Zündvorgang endet, sobald Sie den Zündknopf loslassen bzw. automatisch nach ca. 6-8 Sekunden dank des integrierten Überlastschutzes. Sollte das CL 4 wegen des Überlastschutzes automatisch abschalten, lässt sich der nächste Zündvorgang erst nach einer kurzen Kühlphase durchführen.

4. CE Kennzeichnung und Entsorgungshinweis

Ihr Gerät trägt das CE-Zeichen und erfüllt alle erforderlichen EU-Normen. Hiermit erklärt die TELESTAR DIGITAL GmbH, Am Weiher 14, 56766 Ulmen, dass sich das Gerät inoLight CL 4 in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen befindet. Die Konformitätserklärung für dieses Produkt erhalten Sie auf: www.telestar.de/inolight-leds/Aktionsartikel/Stabanzuender.



Entsorgen Sie Akkus und Batterien niemals über den Hausmüll, da hierfür eine gesetzliche Rückgabepflicht besteht.



Diese müssen gemäß behördlichen Auflagen entsorgt und der Wiederverwertung zugeführt werden. Die Batterien/Akkus werden recyclet, da sie z.B. Nickel-Cadmium (Ni-Cd), Blei (Pb), Cadmium (Cd) oder Quecksilber (Hg) enthalten können.



inolight CL 4 USB plasma lighter



1. Basic information

Thank you for purchasing this product. When you use the CL 4 for the first time, please read these instructions carefully, and retain them for reference in future. If you have a technical question, feel free to contact our service team via email (service@telestar.de).

2. Safety notice

Please read the safety notices carefully before operating the lighter. Please note all warnings and instructions both on the product and in the operating manual.

- Do not use violence on this product (e.g. by using sharp objects).
- Keep the lighter out of reach of children.
- Always leave maintenance or repair work to qualified personnel. Ignoring this may endanger yourself and others.
- The lighter should not be exposed to water or other liquids.
- To remove wax residue from the poles (see pic. 4) please use a nail file.
- In order to charge the lighter, please use only a USB port of a laptop or a mobile charger featuring a maximum power of 5V DC and 3000 mA. Inappropriate use may result in danger of explosion!
- Do not use the lighter for illumination purposes..
- Please keep enough distance between the lighter and your own and others faces, skin and inappropriate inflammable material. In order to prevent from danger, please ensure that the electric arc is completely switched off after using the product.
- Keep the product away from flames, direct sun exposure and temperatures higher than 50 degrees Celsius in order to avoid overheating, fire and malfunction or to shorten the product's life cycle.
- Remove the charger immediately after completing the charging process.

3. Operation

The inoLight CL 4 is equipped with a rechargeable Li-Ion battery (3.7V, 280 mAh). Thanks to booster technology, the low current potential is amplified to half-sinus high voltage (up to 7kV and 15 kHz frequency), creating a light arc that features extremely high temperatures. Thus, the lighter is suitable to easily ignite cigarettes, candles, campfires and other inflammable material. There's no need to use fossil fuel anymore - the inoLight CL 4 is easily charged via USB in just under 3 hours and one charging lasts for about 100 ignitions.

- Fully charge the lighter prior its first use by using a USB port (e.g. of a laptop) or a mobile charger (max. power 5V DC, 3000 mA). Connect the device (see pic. 1) with the charger by using the included USB cable.
- The charging process takes between 2 and 3 hours. Please remove the device from the charger, it is now fully operational.
- Move the safety cover (see pic. 2) to top position and push the ignite button (see pic. 3). Now bring the light arc to the material you want to ignite (see pic. 4).
- Ignition process ends as soon as the ignite button is released or if the electronic overload protection kicks in after 6-8 seconds of ignition. If the CL 4 shuts down because of electronic overload protection, the next ignition may be delayed due to a short cooling phase.

4. CE tag and disposal note

Your device bears the CE mark. TELESTAR-DIGITAL GmbH, Am Weiher 14, 56766 Ulmen states that this product complies with all required EU standards. CE mark for European markets. The CE mark on the product inoLight CL 4 gives you the assurance that the product complies with the CE regulations. The conformity declaration for this product can be obtained at www.telestar.de/inolight-leds/Aktionsartikel/Stabanzuender.

Please ensure that spent batteries and rechargeable batteries are disposed of professionally, and not discarded in your domestic waste. The batteries and rechargeable batteries may contain materials, such as Mercury (Hg), Lead (Pb), Cadmium (Cd) and others. By making these materials available for re-use, you are making an important contribution to the protection of our environment. Please contact your local authority to find your local disposal centre.

