

Document No. SYSC-0-100108

January 2010

**Digital Storage Oscilloscope
Communication&Control Software
User Manual and Installation Instructions**

Copyright Information

1. Uni-Trend Technology (China) Limited. All rights reserved.
2. Products of the Company are protected by patents granted and pending in the People's Republic of China.
3. Information contained in this manual supercedes all information in previously published versions.
4. The Company reserves the right to change specifications and prices.

Note : Uni-T is the registered trademark of Uni-Trend Technology (China) Limited.

Table of Contents

Chapter 1 Installing the communication and control software for your

digital storage oscilloscope.....4

1.1 Hardware requirements	4
1.2. Installing the software	8
1.3 Installing the driver	8
1.4 Software startup	13

Chapter 2 Getting to know your digital storage oscilloscope

communication and control software.....15

2.1 The control panel	15
2.2. Main menu	16

Chapter 3 Operation guide for the digital storage oscilloscope

communication and control software.....18

3.1 USB interface controls	18
----------------------------------	----

Chapter 4 System Prompts and Trouble-shooting.....21

4.1 System prompts.....	21
4.2 Trouble-shooting	21

Chapter 1 Installing the communication and control software for your digital storage oscilloscope

1. Hardware requirements

Equipment requirements	Minimal
Oscilloscope	UTD2000M Series Digital Storage Oscilloscope
Computer	Windows 2000/XP/Vista, 128 MB RAM, 16X CD-ROM or better (Vista users please refer to its individual hardware requirements), VGA display or better, high speed USB2.0 interface.
Connection cable	Two-terminal USB/HOST connection cable

2. Installing the software

Your UTD2000M Series Digital Storage Oscilloscope (“Oscilloscope”) comes with an oscilloscope communication and control software (contained in the CD-Rom supplied with your oscilloscope).

File name: Monitor & Controller Software for UTD2000M V1.8

Installation :

Step one : Insert the CD-Rom supplied with your oscilloscope in the CD-Rom drive of the computer. Wait for the system to read and find the oscilloscope communication and control software contents (Figure 1-1)



Figure 1-1

Note : 1. The installation pack downloaded online must be unzipped before application.

2. The software supports Windows 2000, Windows XP and Vista operating systems. On Vista only USB2.0 communication protocol is supported.

Step two : Double left click the mouse to run the oscilloscope communication and control software installation as shown in Figure 1-1. A welcome screen

will pop up automatically to guide you through software installation, as shown in Figure 1-2 :




Figure 1-2

Step three : Read the prompt in Figure 1-2 then click the **NEXT (N)** button to enter the next step, as shown in Figure 1-3




Figure 1-3

Step four : In Figure 1-3, click the **CHANGE (H).....** button to specify the installation path of the software, then click **NEXT**. You can also click **NEXT** directly to use the default path. Enter the screen shown in Figure 1-4.




Figure 1-4

Step five :When automatic installation is complete and the box shown in Figure 1-5 pops up, click the **FINISH (F)** button. Your oscilloscope communication and control software is now successfully installed on your computer and ready for use.

To return to the screen of the previous installation step, click **BACK (B)** on any installation guide page.

To stop installation, press **CANCEL (C)** on any installation guide page.



Figure 1-5

3. Installing the driver

After installing the oscilloscope communication and control software, if you intend to use the USB port of the oscilloscope for software communication and control, you must install the USB driver. You can do this either by manual pre-installation or automatic installation :

(1) Manual pre-installation of the USB driver

Installation steps are as follows :

Step 1 : Insert the CD-Rom supplied with your oscilloscope in the CD-Rom disk drive of the computer. Wait for the system to read the CD-Rom and find the DSO_USB interface driver (Figure 1-8).



Figure 1-8

Install DSO_USB_Driver (Cy68013) (Figure 1-9).



Figure 1-9

Double left click the mouse to run DSO_USB_Driver. An installation box will pop up (Figure 1-10). Click the **Next** button to enter the automatic installation page.




Figure 1-10

Step 3 : When automatic installation is complete, as indicated by the pop-up box in Figure 1-11, click **Finish** in Figure 1-11. Your USB driver is now successfully installed on your computer and ready for use.




Figure 1-11

(2) Automatic Installation

1. There is a USB device port on the rear panel of your UTD2000E_3000E Series Digital Storage Oscilloscope. With the supplied USB A-B cable, you can connect the USB device port to the USB Host port of the computer and obtain power supply for the oscilloscope.

2. After checking that connection and power supply are normal, power on the digital storage oscilloscope. When the operation status screen appears, a prompt will appear at the right bottom corner to indicate “New hardware DSO detected”, as shown in Fig 1-12.



Figure 1-12

Next, an icon will be created for the “New hardware DSO detected”, as shown in Fig 1-13.



Figure 1-13

Then a “hardware update wizard” dialog box will pop up on the desktop, as shown in Fig 1-14.




Fig 1-14

3. In the new hardware wizard dialog box in Fig 1-12, select the “automatic software installation (recommended) (I) option, then click [NEXT (N)] to enter the automatic driver search and installation page, as shown in Fig 1-15.




Figure 1-15

4. As shown in Fig 1-15, the hardware installation wizard of your digital storage oscilloscope begins automatic searching and installing the USB driver for the oscilloscope communication and control software. When installation is complete the dialog box shown in Fig 1-16 pops up.




Figure 1-16

5. In Fig 1-16, click the [FINISH (E)] button. Your USB driver is now installed, and instant communication and control are enabled between the oscilloscope and the software. Please read “3.1 USB Interface Controls” in “Chapter 3 : Operation guide for the oscilloscope communication and control software” of this booklet prior to operation.

4. Software startup

After successful installing the digital storage oscilloscope communication and control software, you can start the software on the computer in two ways.

- (1) After successful installation of the software, a shortcut icon will be automatically created on your computer desktop, as shown in Fig. 1-17. Double left click this icon to start the digital storage oscilloscope communication and control software.



Figure 1-17

- (2) Alternatively, you can start the software as follows : START→Programmes→DSO real-time monitor→DSO real-time monitor, as shown in Figure 1-18.




Figure 1-18

- (3) In the pop-up dialogue box, select the interface type that matches your oscilloscope model (Figure 1-19).



Figure 1-19

- (4) Click **ENTER** to enter the software control screen.

Chapter 2 Getting to know your digital storage oscilloscope communication and control software

1. The control panel

When the oscilloscope communication and control software is activated, a display panel similar to the digital storage oscilloscope operation interface will pop up. This is the virtual oscilloscope control panel. When transmitting data, you can observe the current waveform displayed by the oscilloscope on the virtual control panel. This interface also features menus, controls and knobs for accessing waveform and channel parameters (please disable the “data transmission” function before using the menus to access information). Please see below for detailed operation instructions :




Figure 2-1

2. Main menu

Figure 2-1 shows two menus under the main menu on the top left corner : document and help. At the bottom of the screen you will find four menus : record path setup, record, playback path setup and playback. Their operation instructions are as follows :

1. Document

Transmitting and saving data : This means saving the waveform on the virtual display to the computer or other storage media. Select DOCUMENT→DATA TRANSMISSION & SAVE, then save the document in *.sav format on the computer hard disk or a mobile hard disk. You can name the document in anyway you like.

Return : Return to the model selection menu.

2. Help

Major functions of the digital storage oscilloscope communication and control software are displayed.

◆ **Remote monitoring and control :** You can control your digital storage oscilloscope remotely with the communication and control software. In the remote control mode, the computer will show a virtual display and control panel similar to the control panel of the digital storage oscilloscope. The virtual control panel is shown in Figure 2-2.




Figure 2-2

The sign of every button or knob on the virtual control panel is identical to that on the oscilloscope control panel. You can click the same buttons to operate the corresponding functions. To use the virtual control panel efficiently, you must be familiar with all function menus as well as the current status of the oscilloscope. Waveforms on the virtual display panel are updated in real time and maintain synchronized with the waveforms on the oscilloscope.

Chapter 3 Operation guide for the digital storage oscilloscope communication and control software

By now you should have grasped the basic structure, menu options and functions of the oscilloscope communication and control software. In the following pages you will find more detailed instructions on how to operate the software. In this chapter, we will give guidance on the USB control mode.

USB interface controls

To enjoy optimal software performance, we recommend you to read the oscilloscope user manual and this chapter to familiar with application.

After installing the software and driver properly, connect the two ends of the USB/HOST cable. Power on the oscilloscope and activate the software. The software control panel shown in Figure 3-1 will appear on your computer screen, where you can select software model and interface type.




Figure 3-1

Select the model and interface type that match your oscilloscope. Click to enter. A communication and control software control screen shown in Figure 3-2 pops up.




Figure 3-2

Click the **Connect** button to turn the equipment “ON”. The button now changes into **Disconnect**. When set to **Disconnect**, it is “OFF”, as shown in Figure 3-3.



Figure 3-3 Connect Equipment and Disconnect Equipment

To enable the remote control mode, click the **Connect** button to change it to “ON”. Use the buttons on the virtual control panel (Figure 3-4) as instructed by the oscilloscope user manual to control your digital storage oscilloscope.




Figure 3-4

When operation is complete, click **Disconnect**, then click **Return** to close the remote control window and quit remote control.

Chapter 4 System Prompts and Trouble-shooting

1. System prompts

Equipment connection or model error : Check the selected oscilloscope model and communication interface type. Also see if the equipment is correctly connected, or if the software driver is the update version.

2. Trouble-shooting

(1) If connection fails after pressing CONNECT EQUIPMENT, take the following steps :

- ① Check whether the oscilloscope power plug is properly connected.
- ② Check the setups of the oscilloscope and the control software.
- ③ Check whether the cable connection between module and PC is in order.
- ④ Ensure the USB driver is properly installed.
- ⑤ After carrying out the above checks, restart the software and oscilloscope to continue operation.

(2) If you are unable to update the software driver, take the following steps :

- ① Right click on your computer desktop as shown in Figure 4-1 to activate the right-click menu in Figure 4-2.




Figure 4-1

Figure 4-2

- ② In Figure 4-2, select ATTRIBUTE and right click to pop up Figure 4-3.




Figure 4-3

- ③ Select HARDWARE in Figure 4-3. Figure 4-4 is displayed.




Figure 4-4

- ④ Select EQUIPMENT MANAGER (D) in Figure 4-4. Figure 4-5 pops up.




Figure 4-5

- ⑤ In EXTERIOR INTERFACE in Figure 4-5, delete OSCILLOSCOPE to restart the oscilloscope. Select automatic driver update to upgrade the software.

Note : When the communication and control software is communicating with the digital storage oscilloscope, do not unplug the connection cable to disconnect communication. This may cause abnormalities.

Copyright Statement

Copyright of this User Manual is owned by Uni-Trend Technology (Chengdu) Limited. Unless with prior written authorization from the company, no individual or firm may publish or change any contents herein contained in any way whatsoever.

Thank you!